

NEW CLASSIC® Home Furnishings, Inc.

1040 Versaille / 013 Belle Rose Collection

Instructions for attaching decorative wood brackets to side rails.
(Updated 1-12-2011)

Included: 4 Decorative wood brackets with screws to secure to side rail



Place side rail upside down on soft surface to prevent scratching. Line up decorative bracket with the edge of the side rail.



Before attaching, make sure decorative wood bracket is flush with the edge and outer face of the side rail



Use screws to secure decorative wood bracket to the side rail through the predrilled holes in the mounting block on the bracket.



After Mounting to the side rail, attach rail to headboard or footboard.



Secure the Decorative bracket to the headboard or footboard by attaching with screws through the pre drilled holes in the mounting block